

Leaf -539	Shine -126	Pumpkin -316	Poppy -314	Berry -542	Splash -538	Cloud -540	Mojito -541	Gizeh -839	Cliff -844	Shell -133
--------------	---------------	-----------------	---------------	---------------	----------------	---------------	----------------	---------------	---------------	---------------

	Leaf -539	Shine -126	Pumpkin -316	Poppy -314	Berry -542	Splash -538	Cloud -540	Mojito -541	Gizeh -839	Cliff -844	Shell -133
TELLER										coming soon	coming soon
Essteller Ø 24 cm, 67 g, Art.-Nr.: 0624-											
Suppenteller Ø 19 cm, 90 g, Art.-Nr.: 0635-											
Teller tief Ø 20,5 cm, 101 g, Art.-Nr.: 0574-											
Frühstücksteller Ø 20 cm, 83 g, Art.-Nr.: 0617-											
Dessertteller Ø 19 cm, 78 g, Art.-Nr.: 0572-											
Untertasse Ø 13,5 cm, 45 g, Art.-Nr.: 0609-											
KANNE											
Kanne mit Deckel 1,0 l, 273 g, Art.-Nr.: 0645-											
Deckel für Kanne Art.-Nr.: 0645D01-											
BESTECK											
Löffel 15,5 cm, 25 g, Art.-Nr.: 0634-											
BECHER & TASSEN											
Kindertasse 0,15 ml, 64 g, Art.-Nr.: 0608-											
Henkelbecher 0,20 ml, 61 g, Art.-Nr.: 0603-											
Trinkbecher 0,25 ml, 71 g, Art.-Nr.: 0663-											
EIERBECHER											
Eierbecher 2-er Set, 148 g, Art.-Nr.: 0710-											
SCHALEN											
Universalschale Ø 16,5 cm, 206 g, Art.-Nr.: 0652-											
Müslischale Ø 13,5 cm, 133 g, Art.-Nr.: 0651-											
Dessertschale Ø 11 cm, 75 g, Art.-Nr.: 0650-											
Dessertschale Ø 13,5 cm, 45 g, Art.-Nr.: 0649-											